



Care & Maintenance Guide



Everyday Cleaning

Caesarstone® requires very little maintenance to keep the surface looking like new. For everyday, routine cleaning of Caesarstone® we recommend wiping the surface with warm soapy water (a mild detergent) and a damp cloth, or use our convenient Caesarstone® Cleaning Wipes or Caesarstone® Spray Cleaner which are available to purchase from our online shop.

As Caesarstone® is virtually non-porous, it will keep its lustrous gloss and ultra smooth surface without polishing and it never needs sealing. Never attempt to polish the surface on your own, and avoid prolonged rubbing in one spot when cleaning.

Caesarstone® Cream Cleanser

Caesarstone® Cream Cleanser has been specially formulated to remove the most stubborn stains such as red wine or beetroot while taking care of your Caesarstone® surfaces. It is also suitable for cleaning sinks and taps, baths and basins, shower recesses, tile surfaces and cook tops.

Food Preparation

We always recommend cutting on an appropriate cutting board and never directly on the Caesarstone® surface to avoid blunting kitchen knives or damaging the surface of your bench top.

Warranty Registration

Have you registered your Caesarstone® 10 Year Limited Warranty yet? Do it online to receive a free Caesarstone® Cleaning Kit to help maintain the look of your surface for years to come.

Cleaning Reference Guide

Substance	Caesarstone® Cream Cleanser	Methylated Spirits	Caesarstone® Spray Cleaner
Red Wine	✓		
Beetroot	✓		
Coffee / Tea	✓		
Cordial	✓		
Spices	✓		
Food Oils			✓
Glue / Silicone / Paint		✓	

Heat Resistance

Caesarstone® is heat resistant, however like all stone materials; Caesarstone® can be damaged by sudden and rapid surface temperature changes. A good rule of thumb is that if your hand cannot tolerate the level of heat for more than a few second then the heat source is too high. Therefore we always recommend placing hot pots, oven trays and fry pans directly from the oven or hot plate onto a wooden chopping board or heat trivet. We also recommend that electric fry pans and slow cookers are also used on a wooden chopping board.

Tough? Yes. Indestructible? No.

As with any surface, Caesarstone® can be permanently damaged by exposure to strong chemicals and solvents that undermine its physical properties. Do not use products that contain trichlorethane or methylene chloride, such as paint removers or stripper. Avoid any highly aggressive cleaning agents like oven cleaner that have high alkaline/pH levels. Should the surface be accidentally exposed to any of these damaging products, rinse immediately with water to neutralize the effect.

Extra Stubborn Stains

If you have an extra stubborn stain which can't be removed with Caesarstone® Cream Cleanser, don't panic! Simply contact our Caesarstone® customer support team at 1300 119 119 who will be able to provide you with further cleaning advice for your specific type of stain.

Caesarstone® Cleaning Products

Caesarstone® has developed a range of cleaning products specially designed and formulated to keep your quartz surfaces looking their best. Caesarstone® Cream Cleanser, Cleaning Wipes and Spray Cleaner are now available to purchase through our online store at www.caesarstone.com.au



caesarstone®

Cream Cleanser

Recommended for cleaning
CaesarStone Quartz Surfaces

Also suitable for cleaning:

- Sinks and taps
- Baths and basins
- Shower recesses and tile surfaces
- Cook tops

250ml

caesarstone®


Spray Cleaner

Recommended for everyday cleaning
of Caesarstone® Quartz Surfaces

Also suitable for cleaning:

- Sinks and taps
- Baths and basins
- Shower recesses
- Tile surfaces
- Cook tops

500ml



How to use Caesarstone® Cream Cleanser

For removal of extra stubborn stains, or if you wish to give your Caesarstone® surface a thorough clean then we recommend Caesarstone® Cream Cleanser and a 3M™ Scotchbrite™ Never Scratch™ All-Purpose Scrubber which can be used without damaging the stone, or alternatively applied to a soft damp cloth.

When using Caesarstone® Cream Cleanser, apply a generous amount to the bench top then gently work it into a thick foam using a 3M™ Scotchbrite™ Never Scratch™ All-Purpose Scrubber which has been drenched in warm water. Gently scrub the stain in a circular motion, adding more warm water if necessary while being careful not to rub in one spot for too long. Use the scrubber to clean the entire bench top before rinsing with more water then buffing the surface dry with a soft, clean towel.

To remove adhered materials like food, gum and nail polish, first scrape away the excess with a sharp blade. If there are any grey metal marks on the surface, a mild detergent will remove it. Household bleach can generally be used as an effective cleaner to remove stubborn marks, but care should be taken as some products are considerably stronger than others.

For Motivo™ pattern textured collection it may also be necessary to use a non-abrasive soft bristle brush for extra stubborn stains.



Go on, express yourself with Caesarstone

We'd love to hear from you. For more design ideas, information and for your nearest showroom, visit our website:

www.caesarstone.com.au or call us on 1300 119 119.

Caesarstone® and other Caesarstone® marks are trade marks of Caesarstone® Sdot-Yam Limited and they are used under licence by Caesarstone® Australia Pty Ltd. 3M, Scotch – Brite and Never Scratch are all trademarks of 3M Company.
Printed September 2015. © Copyright Caesarstone 2015
This document supersedes all previous versions and is subject to change without notice.